

SPECIFICATION

Model: Voyage Bluetooth® Speaker
Bluetooth Specifications: Bluetooth® V3.0
Transmission distance: up to 10 m (This may vary based on environmental factors or the type of Bluetooth® device being used)
Built-in battery: Lithium Battery 300mAh
USB Recharge voltage: DC 5V
Output power: 3W
Frequency Response: 90Hz-20Khz
Sensitivity: 80db±2db
Product dimensions: 2" x 2" x 2"

PACKING

- Bluetooth® Speaker with strap
- Mini USB Charging Cable
- User Manual


Voyage Bluetooth® Speaker

Instruction Manual

Back Cover

Front Cover

GENERAL FUNCTIONS



page 02

BLUETOOTH OPERATION

1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.
2. Turn the speaker on, the indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode. The indicator light will go off if no Bluetooth devices are detected within 5 minutes.
3. "GEMLINE SPKR" will appear on the Bluetooth device list, select "GEMLINE SPKR" to establish pairing. If instructed to enter a PIN code, please enter '0000'.
4. When you want to play audio from another Bluetooth device, disconnect the speaker from the original device and follow steps 1-3 to re-pair the speaker with a new Bluetooth enabled device.

page 03

AUX PLAYBACK OPERATION

1. Turn on the speaker.
2. Connect the speaker to a smartphone, audio device, or laptop
3. The volume, play/pause, and next/previous song button can only be adjusted on the device that is connected through the 3.5mm AUX cable (AUX Cable not included).

CHARGING THE SPEAKER

1. When the battery is low, please charge via the included Mini USB cable. The charging time is approximately 1 hour and provides up to 2 hours of continuous operation.
2. The LED indicator light will be red during charging and will turn off once it is fully charged.

page 04

WARNING

1. Do not disassemble, repair, or modify the speaker.
2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.
3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the speaker.
4. Keep the speaker dry and do not store the speaker in damp areas to avoid damage to the speaker.
5. Avoid dropping the speaker as it may damage the speaker.

KIND REMINDER

1. To prolong the speaker's life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
2. When an error occurs with the speaker, please turn off the speaker and restart it to troubleshoot.
3. When the speaker's power is low, the Bluetooth range may be affected. Please charge the speaker to avoid disruptions during use.

page 05

PROBLEM	TROUBLESHOOTING METHOD
Unable to pair the speaker with a mobile device	1. Inspect whether the speaker is searching for a Bluetooth enabled device to connect to. If not, restart the headphones. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the speaker.
The music stops from time to time	1. Inspect the distance between the speaker and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the speaker and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the speaker.

page 06

PROBLEM	TROUBLESHOOTING METHOD
The sound is low or distorted	1. Inspect the volume of the connected speaker or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the speaker.
The Bluetooth indicator light remains OFF	1. The power of the battery is insufficient, please recharge the speaker. 2. Restart the speaker.

page 07